

Flush Shutter

Z-Wave Gateway Compatibility

!NOTE: Qubino Flush Shutter is Z-Wave certified and it should work with **ALL** Z-Wave certified gateways.

The following list contains **ONLY** the gateways which have been tested with Qubino modules.

If you're missing a specific gateway, it means that the gateway was not tested with this Qubino module

Legend: UP - Supported DOWN - Not Supported

Gateway	Supported functions						
Aeotec Autopilot v1.1.5	UP	DOWN	Set Position	Tilt Angle	Measure Temperature	Watts	
Athom Homey v3.1.0 (Qubino app v3.0.2)	UP	DOWN	Set Position	Tilt Angle	Measure Temperature	Watts	
Bosch IoT Gateway Software v9.2 zw5.0.5	UP	DOWN	Set Position	Tilt Angle	Measure Temperature	Watts	
Domoticz v3.9052-STABLE	UP	DOWN	Set Position	Tilt Angle	Measure Temperature	Watts	
EKZ Smart Home HUB v3.0.0	UP	DOWN	Set Position	Tilt Angle	Measure Temperature	Watts	
Futurehome CUBE-1V1-EU v2.0.0	UP	DOWN	Set Position	Tilt Angle	Measure Temperature	Watts	
HomeSeer v3.0.0.535	UP	DOWN	Set Position	Tilt Angle	Measure Temperature	Watts	
OpenZWave v1.4 + OpenZWave Control Panel	UP	DOWN	Set Position	Tilt Angle	Measure Temperature	Watts	
Schwaiger HA101 v4.1.0	UP	DOWN	Set Position	Tilt Angle	Measure Temperature	Watts	
Silicon Labs Zware zip7.14.02.1zware7.14.2.0	UP	DOWN	Set Position	Tilt Angle	Measure Temperature	Watts	
VeraEdge v1.7.4969	UP	DOWN	Set Position	Tilt Angle	Measure Temperature	Watts	
Allonis myServer v6.0.24.32664	UP	DOWN	Set Position	Measure Temperature	Watts		Tilt Angle
Animus Heart fw 2.0.2 sys 2.0.0	UP	DOWN	Set Position	Measure Temperature	Watts		Tilt Angle
Comfort Click Colibri (bOS Configurator v4.6.20)	UP	DOWN	Set Position	Measure Temperature	Watts		Tilt Angle
Eedomus+	UP	DOWN	Set Position	Measure Temperature	Watts		Tilt Angle
FHEM v5.9	UP	DOWN	Set Position	Measure Temperature	Watts		Tilt Angle
Fibaro Home Center 2 v4.580	UP	DOWN	Set Position	Measure Temperature	Watts		Tilt Angle
Fibaro Home Center 3 v5.050.13	UP	DOWN	Set Position	Measure Temperature	Watts		Tilt Angle
Fibaro Home Center Lite v4.550	UP	DOWN	Set Position	Measure Temperature	Watts		Tilt Angle
Homee v2.24.1	UP	DOWN	Set Position	Measure Temperature	Watts		Tilt Angle
HomeSeer v4.1.2.0 zw 3.0.2.0	UP	DOWN	Set Position	Measure Temperature	Watts		Tilt Angle
Hubitat Elevation	UP	DOWN	Set Position	Measure Temperature	Watts		Tilt Angle

Gateway	Supported functions					
<i>ImperiHome</i> (app for VeraEdge)	UP	DOWN	Tilt Angle	Measure Temperature	Watts	Set Position
<i>Indigo Domotics</i> v7.3	UP	DOWN	Set Position	Measure Temperature	Watts	Tilt Angle
<i>Ingelec</i> DMPASS01 v040202	UP	DOWN	Set Position	Measure Temperature	Watts	Tilt Angle
<i>Jeedom</i> v3.2.12	UP	DOWN	Set Position	Measure Temperature	Watts	Tilt Angle
<i>Mediola</i> AIO Gateway V5+ v1.1.13	UP	DOWN	Set Position	Measure Temperature	Watts	Tilt Angle
<i>Popp</i> HUB v2.3.8	UP	DOWN	Set Position	Measure Temperature	Watts	Tilt Angle
<i>Rostelecom</i> HUB1-B (ZwaveMe v2.3.8)	UP	DOWN	Set Position	Measure Temperature	Watts	Tilt Angle
<i>StarVedia</i> G1 v040202	UP	DOWN	Set Position	Measure Temperature	Watts	Tilt Angle
<i>Universal Devices</i> Gateway ISY994 v5.0.14MK	UP	DOWN	Set Position	Tilt Angle	Measure Temperature	Watts
<i>WeBeHome</i> HG2+ v4.07.04	UP	DOWN	Set Position	Measure Temperature	Watts	Tilt Angle
<i>Zipato</i> Zipatile v1.3.61j	UP	DOWN	Set Position	Tilt Angle	Watts	Measure Temperature
<i>Z-Wave.Me</i> v3.0.6	UP	DOWN	Set Position	Measure Temperature	Watts	Tilt Angle
<i>Home Assistant</i> v0.97.2	UP	DOWN	Measure Temperature	Watts	Set Position	Tilt Angle
<i>OpenHAB2</i> v2.4.0-STABLE	UP	DOWN	Tilt Angle	Watts	Set Position	Measure Temperature
<i>Schwaiger</i> HA101 v3.3.0	UP	DOWN	Tilt Angle	Watts	Set Position	Measure Temperature
<i>Telldus</i> TellStick Znet LiteV2 v1.2.0	UP	DOWN	Measure Temperature	Watts	Set Position	Tilt Angle
<i>A1</i> Smart Home v859	UP	DOWN	Set Position	Tilt Angle	Measure Temperature	Watts
<i>Devollo</i> v8.84.1 2019-05-17	UP	DOWN	Watts	Set Position	Tilt Angle	Measure Temperature
<i>Ezlo</i> Atom v0.8.98	UP	DOWN	Set Position	Tilt Angle	Measure Temperature	Watts
<i>Ilevia</i> EVE X1 Server v4.3.2.5.eden	UP	DOWN	Set Position	Tilt Angle	Measure Temperature	Watts
<i>Samsung</i> SmartThings v000.021.00012	UP	DOWN	Set Position	Tilt Angle	Measure Temperature	Watts
<i>VitrumDesignUFO</i> Vmo1.2.7 Vda 2.1.4	UP	DOWN	Set Position	Tilt Angle	Measure Temperature	Watts
<i>Zipato</i> Zipabox v1.3.24	DOWN	Set Position	UP	Tilt Angle	Measure Temperature	Watts
<i>Domoticz</i> v4.11213-BETA	Measure Temperature	UP	DOWN	Set Position	Tilt Angle	Watts