



**Caution:**  
When the product is used outdoors  
the mains plug must be connected to  
socket outlet located indoors

# WiZ





WiZ Fairy Light Manual  
9290041012, 9290041013  
9290041016


Incl.



1




9290041012 9290041013 9290041016




2



3



4



5

